




---

# Nordik HVSL Super Blade

CE



---

COD. 5.471.084.553

18/11/2016

VORTICE LIMITED  
Beeches House - Eastern Avenue  
Burton on Trent  
DE13 0BB  
Tel. (+44) 1283-492949  
Fax (+44) 1283-544121  
UNITED KINGDOM

VORTICE FRANCE  
72 Rue Baratte-Cholet  
94106 Saint Maur Cedex  
Tel. (+33) 1-55.12.50.00  
Fax (+33) 1-55.12.50.01  
FRANCE

VORTICE ELETTROSOCIALI  
S.p.A.  
Strada Cerca, 2 - frazione di Zoate  
20067 TRIBIANO (MI)  
Tel. (+39) 02-90.69.91  
Fax (+39) 02-90.64.625  
ITALIA

# CONTENTS

<b>1</b>	<b>INTRODUCTION .....</b>	<b>3</b>
1.1	General warnings .....	3
1.2	Conventions used in this manual .....	3
1.3	Glossary and pictograms .....	4
<b>2</b>	<b>GENERAL INFORMATION .....</b>	<b>9</b>
2.1	Application .....	9
2.2	Versions .....	9
2.3	Machine identity data and data plates .....	10
2.4	Manufacturer's identity details .....	10
2.5	Diclarations .....	11
2.6	Description of the parts .....	12
<b>3</b>	<b>TRANSPORTATION AND HANDLING .....</b>	<b>14</b>
3.1	Handling .....	14
3.2	Operative instructions .....	14
3.3	Warranty .....	15
3.4	Storage and landing-up .....	15
<b>4</b>	<b>ASSEMBLY .....</b>	<b>15</b>
<b>5</b>	<b>INSTALLATION .....</b>	<b>16</b>
5.1	Preliminary operations .....	16
5.2	Positioning .....	16
5.3	Optimum installation conditions .....	16
5.4	Tightening torque .....	17
5.5	Tie bars .....	17
5.6	Noise emissions .....	17
5.7	Cleaning .....	17
5.8	Electrical connection .....	17
<b>6</b>	<b>OPERATION .....</b>	<b>18</b>
6.1	Preliminary operations .....	18
6.2	Starting for the first time .....	18
6.3	Emergengy stoppage .....	18
6.4	Starting .....	18
<b>7</b>	<b>MAINTENANCE .....</b>	<b>19</b>
7.1	Routine maintenance .....	19
7.2	Periodic checking .....	19
7.3	Extraordinary maintenance .....	20
<b>8</b>	<b>TECHNICAL CHARACTERISTICS .....</b>	<b>20</b>
8.1	Technical data .....	20
8.2	Spare parts list .....	21
<b>9</b>	<b>TROUBLESHOOTING .....</b>	<b>22</b>

# 1 INTRODUCTION

## 1.1 General warnings

- Make sure you have a complete copy of this manual and the enclosed Assembly Instructions available. Read both documents fully and make sure you understand them adequately before proceeding with subsequent steps. If you have any doubt about a task to be carried out, apply the criterion of maximum personal and collective safety. Immediately interrupt your work, make everything done so far in complete safety, and ask for adequate instructions, if necessary, from the manufacturer as well.
- Check the integrity of the equipment when opening the packaging. Pay particular attention to damage to or deformation of mechanical parts, which may result in breakage and/or malfunctions when in use. If any of these are found, do not connect the machine to the power supply. Carry out these checks every time before use.
- Before connecting the machine to the power supply, check that the indications on the data plate correspond to the electricity supply. The data plate is located on the electronic motor (see par. 1.9).
- Each and every person that may come into contact in any way with the product marketed by Vortice S.p.A., and described here, must be adequately informed by the purchaser of about use, risks, dangers and safety procedures, in the ways provided for by law and as described below in this document.

Conform to the safety norms indicated for electrical equipment, and especially:

- Conform to the assembly and installation instructions for the equipment.
- Do not put items on top of the ceiling fan, and do not hang anything from the ceiling fan's blades.
- Do not touch the ceiling fan when it is running, or immediately after it has stopped. Remember that the motor could be hot.
- Never immerse the equipment in water or any other liquid, and do not use water, especially pressurised, for washing or cleaning the fan or its parts. This equipment is not designed to be impermeable to water. Do not touch the equipment if it gets wet by accident. Immediately disconnect the power supply by switching off the switch on the electrical panel for your system, and immediately disconnect the feeder before touching the equipment. Use suitable means to indicate that reinstating the power supply at the panel is forbidden.
- Do not touch the equipment with wet and/or damp hands.
- Do not use accessories, spare parts and/or components that are not indicated or supplied by the manufacturer.
- Do not pull the power supply cable or expose it to a risk of being sheared.
- If a fault occurs and/or the equipment works badly, switch it off immediately and disconnect the power supply. Use suitable means to indicate that reinstating the power supply at the panel is forbidden. Do not attempt to open or tamper with the equipment. Contact Vortice's technical service department.

## 1.2 Conventions used in this manual

The Manual is broken down into independent chapters, each of which is addressed to a specific type of operator (INSTALLER, MACHINE OPERATOR AND MAINTENANCE TECHNICIAN), for which the skills required to operate on the machine in safety have been defined.

The sequence of the chapters follows the temporal logic of the machine's lifespan.

To facilitate immediate understanding of the text terms, abbreviations and pictograms are used, the meaning of which is indicated below.

### **ABBREVIATION**

Cap.	= Chapter
Par.	= Paragraph
Pag.	= Page
Fig.	= Figure
Tab.	= Table

### **UNIT OF MEASUREMENT**

The units of measurement used are those from the International System (SI).

## Keeping this instruction manual

The instruction manual, along with the enclosed Assembly Manual, must be kept and must stay with the machine through all changes of ownership that may occur during the machine's lifespan.

Anyone who has to come into contact with the ceiling fan in any way or that is involved with using it (due to proximity of the working area, etc.) must be informed of this manual as well as the enclosed Assembly Manual, and adequately trained by the purchaser / user.

Conservation of the same must be facilitated by handling it carefully, with clean hands and avoiding putting it on dirty surfaces.

The parts must not be removed, torn or arbitrarily changed.

The manual and the enclosed assembly manual must be kept in a place protected against damp and heat, and in the immediately vicinity of the machine to which it relates.

The Manufacturer is able to provide further copies of the Instruction Manual and the enclosed Assembly Manual for the machine, if requested by the User.

Such requests should be sent to Vortice Technical Dept. ([www.vortice-italy.com](http://www.vortice-italy.com))

## Recipients

This Manual and the enclosed Assembly Manual are addressed to: The Installer, Operator, and Qualified Personnel authorised to carry out maintenance tasks in the machine.

<b>EXPOSED PERSON:</b>	This means any person who may find themselves fully or partly within the area affected by use of the ceiling fan.
<b>OPERATOR:</b>	This means the person(s) tasked with installing, operating, setting, cleaning, repairing, moving or doing maintenance work on the machine.
<b>QUALIFIED PERSONNEL, QUALIFIED OPERATOR</b>	Person(s) that has/have done a specialisation course, training etc. and that have experience of installing, commissioning, maintaining, repairing or transporting the machine.

This machine is intended for industrial use, and so professional and not general use, which means that it must be entrusted to qualified personnel that are adequately trained in using it by the purchaser, and that especially:

- Are no longer minors.
- Are physically and psychologically suitable for doing particularly difficult technical tasks.
- Have been trained on the use of the personal protection equipment indicated and required.
- Are suitably instructed in using and maintaining the machine.
- Have been adjudged suitable by the employer to do the tasks assigned to them.
- Are able to understand and interpret the operator's manual and safety instructions.
- Know the emergency procedures and how to implement them.
- Have the capacity to operate this specific type of equipment.
- Are familiar with the relevant specific standards.
- Have understood the operating procedures defined by the machine's constructor.

## 1.3 Glossary and pictograms

This paragraph lists uncommon terms or terms whose meaning differs from the common meaning. The abbreviations used and the meaning of the pictograms used to indicate the operator's qualifications and machine status are explained below. Use of the same makes it possible to provide quick, unequivocal information required for correct use of the machine in safety.

## GLOSSARY (Ann. I p. 1.1.1 Dir. 2006/42/EC)

<b>DANGER</b>	A potential source of injury or harm to one's health.
<b>DANGER ZONE</b>	Any zone inside and/or in proximity to the machine in which the presence of a person constitutes a risk to the health and safety of that person.
<b>EXPOSED PERSON</b>	Any person that finds themselves fully or partially in a danger zone.
<b>OPERATOR</b>	The person(s) tasked with installing, operating, setting, cleaning, repairing, moving or doing maintenance work on the machine.
<b>RISK</b>	A combination of the probability and gravity of an injury or damage to one's health that may result in a dangerous situation.
<b>GUARD</b>	A part of the machine used specifically to ensure protection by means of a material barrier.
<b>PROTECTIVE DEVICE</b>	A device (other than a guard) that reduces a risk on its own or in association with a guard.
<b>INTENDED USE</b>	Use of the machine within the limits laid down by the Manufacturer, for which the machine is designed and built, in conformity to the information provided in the instructions for use.
<b>REASONABLY FORESEEABLE INCORRECT USE</b>	Use of the machine in a way that differs from that indicated in the instructions for use, but that may result from human behaviour that can easily be foreseen.

### OTHER DEFINITIONS


<b>MAN-MACHINE INTERACTION:</b>	Any situation in which an operator interacts with the machine, in any operating phase, and at any time in the life of the machine.
<b>OPERATOR'S QUALIFICATION</b>	The minimum skill level the operator must have to carry out the operation described.
<b>NUMBER OF OPERATORS</b>	Number of operators able to carry out the operation described in the best possible way, and resulting from careful analysis by the manufacturer. Therefore, use by a number of different members of staff could prevent the expected result being achieved or put the personnel involved in danger.
<b>MACHINE STATUS</b>	The machine's status includes its operating mode, such as automatic operation, jog mode control, stopping, etc., the condition of the safety devices in the machine, such as guards included, guards excluded, emergency button pushed, type of isolation from energy sources, etc.
<b>RESIDUAL RISK</b>	Risks that remain, despite integrated protective measures being adopted that are integrated in the design of the machine, and despite the additional protective devices and measures adopted.
<b>SAFETY COMPONENT</b>	Component: <ul style="list-style-type: none"><li>- Intended to provide a safety function.</li><li>- A component that, if damaged and/or tampered with, puts the safety of the people involved in jeopardy (e.g. lifting equipment; fixed, mobile or adjustable guard, etc.; electrical, electronic, optical, pneumatic or hydraulic device that serves as, or interlocks a guard, etc.).</li></ul>

## Pictograms related to the operator qualifications

Symbol	Description
	<p>General operator: an operator without specific skills, only able to carry out simple tasks according to the instructions of qualified technicians.</p>
	<p>Lifting and handling gear operator: an operator authorised to use lifting gear and for handling materials and machines (strictly according to the manufacturer's instructions), according to the laws in force in the country in which the machine is used.</p>
	<p>Mechanical maintenance operator: a qualified technician able to operate the machine under normal conditions, to make it work in jog mode with the protective devices deactivated, and do work on the mechanical parts to effect the necessary adjustments, maintenance and repairs. Normally, they are not authorised to work on live electrical systems.</p>
	<p>Electrical maintenance operator: a qualified technician able to operate the machine under normal conditions, to make it work in jog mode with the protective devices deactivated, and do all tasks of an electrical nature involved in adjustments, maintenance and repairs. They are able to work in electrical cabinets and derivation boxes, with the power on.</p>
	<p>Manufacturer's technician: a qualified technician made available by the manufacturer to carry out complex tasks in particular situations or, in any case, as agreed with the user. The skills they possess are of a mechanical and/or electrical and/or electronic and/or software nature.</p>

## Pictograms related to the machine status

The pictograms enclosed in a square / rectangle, provide INFORMATION.

Symbol	Machine status
	Machine off: with the electrical and pneumatic power supplies disconnected.
	Machine running: operating in automatic mode, with mobile guards closed, related interlocking devices activated, and fixed guards closed.
	Machine on: stopped and ready to start (stand-by conditions) by activating an operating activator (e.g. control unit consensus), with mobile guards closed, safety device activated, and fixed guards closed.

## Safety pictograms

Pictograms contained with a triangle indicate DANGER.  
Pictograms contained within a circle impose a PROHIBITION/OBLIGATION.

Pictogram	Name
	High voltage danger
	Entanglement
	Dragging
	General danger
	Do not remove the safety devices
	Cleaning, oiling, greasing, repairing, or adjusting moving parts manually forbidden.
	Obligation to disconnect the power supply before starting work or repairs.
	Protective gloves obligatory
	Safety footwear obligatory

## 2 GENERAL INFORMATION

### 2.1 Application

#### Intended use

Ceiling fan to be installed by fixing to the ceiling, for industrial buildings

This equipment is only to be used for the purpose for which it was expressly designed. Any other use is to be considered improper and dangerous. Vortice S.p.A. cannot be held responsible for any damage resulting from improper, erroneous or unreasonable use, or if the equipment is used with systems that do not conform to the current safety norms.

This machine must be installed where there is a need to cool large closed spaces, such as workshops or industrial departments, factory buildings, etc.

The materials used ensure reliability and durability over time, provided the machine is installed correctly and subjected to suitable maintenance by qualified personnel.



This machine is only to be used for the purpose for which it was designed:  
Ceiling air fan to be installed fixed to the ceiling, for industrial buildings  
All other uses are to be deemed improper and therefore dangerous.



#### Uses explicitly excluded

This product as a whole, including its construction components, is NOT made and therefore must absolutely NOT be used for other purposes such as, by way of example and not exhaustively:

##### ATMOSPHERES:

- Use in atmospheric conditions even only potentially explosive
- Use in aggressive atmospheric conditions
- Use in atmospheric conditions with high salinity or humidity over 90% of that of the standard atmospheric air
- Use in places in which external suspended elements are present (for example, fibres, powders, paints, sand)

##### INSTALLATION:

- Use in outside environments (e.g. lean-to roofs, pergolas, trellises, temporary worksites)
- Use in places that subject the product to vibrations or oscillations (for example: ships, precarious structures, or semi-rigid composite structures such as tents, hot houses, mobile hangars)
- Precarious and temporary use.

### 2.2 Versions

The CEILING FAN comes in the following versions:

- NORDIK HVLS SUPER BLADE 300/120"
- NORDIK HVLS SUPER BLADE 400/160"
- NORDIK HVLS SUPER BLADE 500/200"
- NORDIK HVLS SUPER BLADE 600/240"
- NORDIK HVLS SUPER BLADE 700/280"

### 2.3 Machine identity data and data plates

Each machine is identified by a motor plate that contains its reference details in an indelible state. Whenever contacting the manufacturer or service centres, always quote these reference details.



Fig.1  
The position of the plate on the machine may vary from one machine to another.

### 2.4 Manufacturer's identity details

#### Manufacturer

Vortice Elettrosociali S.p.A.  
Strada Cerca, 2  
Frazione di Zoate  
20067 Tribiano (Milano)  
ITALY

Ph: (+39) 02 906991    [www.vortice-italy.com](http://www.vortice-italy.com)

## 2.5 Declarations

This machine was made in conformity with the pertinent European Directives applicable at the time it was put on the market.

### Declaration of conformity

D. LGS. [Legislative Decree] 17/10 Ann. II lett.A  
European Directive 2006/42/EC Ann.II lett.A

#### **THE MANUFACTURER**

**VORTICE S.P.A.**

*Company*

*Address*

*Post Code*

*Province*

**Italy**

*City*

*Country*

#### **DECLARES THAT THE MACHINE**

**Ceiling Fan    NORDIK HVLS SUPER BLADE 300/120", 400/160", 500/200", 600/240", 700/280"**

*Description*

*Model*

*Serial n°*

*Year built.*

**Ceiling Fan**

*Commercial name*

**Ventilazione di ambienti**

*Intended use*

#### **Conforms to the directive:**

2006/42/EC

and to the legislative provisions that implement the European Directives: Directive 2014/30/EC - Electromagnetic compatibility

Directive 2014/35/EC - Low voltage

**and refers to the following harmonised norms:**

EN 12100, EN 60204-1

**AND AUTHORISES**

*Name*

*Address*

*Postal code*

*Province*

*City*

*Country*


## TO SET UP THE TECHNICAL FOLDER ON ITS BEHALF

<b>Place and date of the document</b>	<b>The manufacturer</b>
	Signed:
	Position  <b>Director</b>

D.C.: DC N-001/290001

### 2.6 Description of the parts

Parts that make up the ceiling fan



NUM.	DESCRIPTION
1	Motor rod holder
2	Welded rod holder
3	Tapered shaft hub
4	Fissing plate
5	Rod 50x50x1470 drilled and galvanized
6	Washer 10,5x20 H2ZN UNI 6592
7	Self-locking nut M10 ZN UNI 7474
8	Screw M10x45 TE ZN UNI 4018
9	Screw M10x35 TE ZN UNI 4018
10	Safety holder
11	Washer Grower diam. 8 zinc.
12	Screw M8x25 TCEI INOX
13	Washer 14 x 36H 2,5 ZN UNI 6593
14	Screw M12x90 TE ZN UNI 4014
15	Self-locking nut M12 ZN UNI 7473
16	Washer Grower diam. 10 galvanized
17	Blade support
18	Fan blade
19	Winglet
20	Washer 8,4 x 16H, 6 ZN UNI 6592
21	Self-locking nut M8 ZN UNI 7473
22	Screw M8x45 TCEI ZN UNI 5931
23	Washer 8 x 24H2 ZN UNI 6593 FL
24	Screw M8x45 TCEI ZN UNI 5931
25	Reinforced Spider folded + Spacer
26	Bottom cup




Fig. 2




Fig.3

## 3 TRANSPORTATION AND HANDLING



Vortice S.p.A. goal is to attain maximum respect for the environment. To this end, and to facilitate the greatest efficiency possible for the end client, it avoids the use of unnecessary or excessive packaging as much as possible, in order to minimise the environmental impact. Unless the purchaser has specific needs or specific requests that are assessed in each case, the product is supplied on a timber pallet inside a cardboard box, where necessary, otherwise it is simply placed in the pallet (e.g. aluminium blades), with parts covered in protective plastic.

The packs must not be stacked.

Avoid damaging the machine's components by being very careful with opening the packaging.

Once delivered to the purchaser, they must immediately check that the product is correct and conforms.

Checking of the integrity of the ceiling fan and the completeness of the package within not more than 48 hours of delivery, is specifically assigned to the user to whom the product is delivered.

No part of the product must be damaged or cracked, or have any other visible defects due to transportation.

All the components must be in the package.

There must be no signs of chemical attack, damp, stains or anything else.

The CE Mark and pictograms must be included, especially:

- The motor's identity label, which also indicates its characteristics.



Do not dispose of packaging in the environment. It must be deposited at specific collection points and stored in accordance with the specific environmental disciplines, by the user.

### 3.1 Handling

The Ceiling Fan is relatively heavy (see weights table) and bulky, and so it must be lifted and handled after having checked that the necessary, suitable equipment is available. They must have personal protection equipment required for the task and called for by applicable local norms. Also, given the weight of the machinery, if suitable lifting devices are not available, the machine and its components must always be handled by at least two people.

In particular:

- For unpacking the product, use at least:
  - GLOVES that are suitably resistant to cuts, perforation and crushing
  - Overalls or approved clothing, type approved in terms of applicable norms
  - Safety footwear
- Operators engaged in unpacking the ceiling fan must be adequately trained and informed by the user of the elements and the dangers they pose.

### 3.2 Operative instructions

- I) Transport the pack that contains the product using adequate equipment, handled / operated by qualified personnel, to the vicinity of the assembly and/or installation site.
- II) Follow all the instructions given in detail. If a passage cannot be understood, or even if there is some doubt concerning it, immediately interrupt operations, make the machine and the parts involved completely safe, and ask for clarification.
- III) Once all UNPACKING operations have been completed, proceed to install in the manner specifically indicated.

The CEILING FAN can be lifted and suspended using the base of the machine as a support. Only lashing and securing methods may be used that ensure the machine's stability and prevent a risk of it falling during the operation. The area underneath must be cordoned off and kept free of people or objects, until after the fan has been started for the first time.

## **WARNING!**

Before moving the equipment, you must:

- a. Stop the machine;
- b. Switch off the power supply;



To lift the machine, use adequate lifting gear (see weights table).

Lift it slowly, being careful that it does not fall, and move the belts according to the centre of gravity. Only lashing and securing methods may be used that ensure the machine's stability and prevent a risk of it falling during the operation.

### **3.3 Warranty**

This equipment is guaranteed for 24 months from the date of production, for any faults due to proven factory or material defects. The guarantee does not cover parts damaged in transit, due to poor or incorrect maintenance, negligence, unskilled use, improper use, tampering by unauthorised personnel and/or, due to any cause for which the Vortice S.p.A. Company is not responsible. During the guarantee period, Vortice S.p.A. undertakes to replace or repair parts of the product free of charge, that are found to have been defective from the outset, provided they are reported by the user immediately or at most within 15 days of discovering the fault in the product.

Malfunctioning of the ceiling fan due to faults in components and/or irregularities relating to parts of the product not reported immediately, in the specific manner indicated in this manual or the sales agreement, may not, under any circumstances, infer responsibility on Vortice S.p.A.'s part, and must be seen to be the user's risk and danger due to unforeseeable use.

Work under guarantee must be done in Vortice S.p.A.'s premises, with transport paid for by the user.

### **3.4 Storage and landing-up**

The product must be kept in a cool, dry place, not subject to high humidity percentages, and correctly positioned on shelves or pallets. Especially the aluminium blades must be placed on adequate shelves, which does not allow them to bend. In any case, when drawn from the stores, check that they are not curved. The product may be stored for 6 months, after which we recommend checking that the electric motor is working properly, before installing it. Check that there are not cracks or breaks in metal parts of the ceiling fan, especially in the blade fixing hub or the blades themselves.

## **4 ASSEMBLY**

**Specific assembly instructions – see the assembly instruction manual**

**Disassembly instructions – see the assembly instruction manual**

## 5 INSTALLATION

### 5.1 Preliminary operations

For the CEILING FAN to work, the following are required:  
Electricity supply with suitable voltage and frequency characteristics for the machine, an earth connection and protective devices;



**Installation must satisfy the safety requirements laid down by current local norms.**



Then check that all the connections necessary for the equipment to work have been formed correctly by expert personnel, according to all the specific disciplines in this regard. Vortice S.p.A. does not accept any responsibility for damage and/or malfunctioning due to connecting the product to the power supply in a manner that does not conform to the requirements laid down herein.

### 5.2 Positioning

Once the ceiling fan has been assembled, installation operations can begin.

Make sure you have understood the enclosed Assembly Instructions fully. To position the unit, the specialist, trained operator, in terms of the requirements above, must take the following precautions:



- The use of specific PPE is absolutely necessary, and in particular the operator must use at least working gloves, approved clothing that ensures high visibility, safety footwear, and a protective device for their head
- Before beginning installation, make sure the place available is suitable for the purpose. Especially check the connections, structure of the support / fixing point, distance from heat sources, high voltage lines, and/or other elements that may interfere with the machine's operation in some way, distance from the ground, and the operators involved.
- Before proceeding with installation, assess the possible interference risks between the operations to be carried out, fixed and moveable equipment to be used, and the working environment in which installation is to be done, according to the reference national norms.
- Proceed to install the product and its control panel in an accessible place that allows regular functioning to be checked visually at all times from the ground. It must also allow quick stoppage in case of emergency, as well as correct routine and extraordinary maintenance by authorised operators.
- Check that no operator is under or in the proximity of the installation site, until after the unit has been used for the first time.
- Make sure that the minimum lighting level in the installation area is at least 50 lux, to allow maintenance to be carried out and the equipment to be identified, as otherwise it may not be seen and perceived when it is running. We also advise against installing the ceiling fan below light sources that may generate a stroboscopic effect, which would be bothersome for the operators.

Once the checks indicated above have been completed, install as per the specific procedures listed below:

**For installing and using the machine for the first time, see annex 1 to this Manual, "Assembly Instructions".**

### 5.3 Optimum installation conditions

The ceiling fan must be installed at least one metre below the ceiling and at a height of 4 metres above the floor. The installer is also to assess any interference with machinery, balconies, balustrades, or anything else between the floor and the machine, that may interfere with it. Before beginning installation, the area must be specifically signposted and cleared of people or objects that may get in the way or be damaged by accidental falling of parts of the machine. The area over which the ceiling fan's action is effective is about 3 times the diameter of the fan. The manufacturer expressly forbids installations in which no space is left between one machine and another equal to the diameter of the machine itself. The installer is fully responsible for connecting the ceiling fan to the ceiling. They must therefore assess the most suitable fixing system in order to ensure that the unit is fixed in a workmanlike manner, according to the type of ceiling, beams or structure in general to which the fan is to be anchored.

## 5.4 Tightening torque

It is necessary use a torque wrench or a calibrated screwdriver in order to respect the following tightening torque:

- M8 Screw: 27 Nm
- M10 Screw: 53 Nm
- M12 Screw: 92 Nm

## 5.5 Tie bars

The Manufacturer markets and provides a specific metal tie bar kit for the ceiling fan, supplied if requested by the purchaser.

This tie bar kit ensures additional axial stability for the ceiling fan, and keeps it at its height if, due to outside causes, the machine is stressed anomalously, or the ceiling assembly with just one central pole, does not ensure adequate solidity over time.

The installation **MUST** be completed using the tie bar kit for safety reasons, if the purchaser or installer finds any of the following, in the actual production situation and installation position of the ceiling fan inside the industrial building involved:

- The possibility that the ceiling fan may be struck by gusts of wind (e.g. opening of doors or windows), or that the ceiling fan is installed in buildings that can be opened on the sides.
- The possibility that the ceiling fan may inadvertently be struck by machines or equipment used by the purchaser or others, working inside the building in which the fan is installed.
- The possibility that the ceiling fan may be struck by flying creatures, flying around inside the building in which it is installed.
- The industrial building is located in an area defined to be seismic or, in any case, subject to appreciable sources of vibrations that affect the building.

**WARNING:** Since the assessment of the need to do the installation with an additional tie bar kit depends completely on objective conditions related to the property, the type of production activity and mode of the same, and these conditions cannot be ascribed to the Manufacturer, the Manufacturer does not accept any responsibility for not using the tie bar kit for installation, while stating that its use is preferable and safer.

Installing the ceiling fan in the presence of winds or draughts that strike the machine on the side, with wind speeds greater than or equal to 14 m/sec, is expressly forbidden. For wind speeds of between 10 and 14 m/sec, use of the tie bar kit for installation is obligatory, and the machine is already set up for the same.

In the case of strong side winds that strike the ceiling fan, in addition to wind bracing in the form of the tie bar kit, it is important that the machine is never stopped, but continues to rotate at minimum revs, in order to balance the side forces that strike it.

We do not advise using the ceiling fan in dusty settings, such as places in which flour or light, easily volatile elements are present.

## 5.6 Noise emissions

The acoustic pressure level of pondered emission A in workplaces does not exceed 70 dB(A).

## 5.7 Cleaning

The machine can be cleaned using products suitable for cleaning aluminium and steel. Each cleaning operation deemed necessary, must be done with the power supply to the machine disconnected. Suitable precautions must be taken to avoid subsequent untimely switch-ons during the operations, and operators must wait until the fan has stopped rotating. Aiming pressurised water towards the ceiling fan for cleaning operations is expressly forbidden, even though the machine is in class IP65.

## 5.8 Electrical connection

The installation involves the use of a control unit with an output of 1 - 10 V. However, as an alternative a manual potentiometer can be used, the only difference being that starting and stopping the machine must be done manually. Each control unit chosen by the client must be CE certified, or must at least conform to the low voltage and electromagnetic compatibility directives. Failure to ensure this will render the warranty null and void, due to damage caused to the machine due to the use of unsuitable material. However, this choice does not affect the installation procedure described below.





- The electrical connection is to be formed by recognised, specialist technicians, authorised in terms of the current norm.
- Make sure that the characteristics of the electricity supply conform to the indications.
- It is mandatory to connect the equipment to an effective earth line.

The installation must include a device for disconnecting the equipment from the mains power supply. A protective fuse must also be installed, adequately sized and of a delayed type for starting motors. Attaching or hanging any object from the ceiling fan's blades for any reason, is forbidden. This is because such actions could result in the machine being out of balance, with a resulting anomalous distribution of loads and consequences such as the machine falling.

**WARNING: SPECIFICALLY INSERT A SINGLE POWER SUPPLY LINE, FITTING A CLASS A TRIP SWITCH IN THE LINE, IN ADDITION TO A PROTECTIVE CIRCUIT BREAKER IS OBLIGATORY. INSTALLING THE CEILING FAN NEAR HIGH VOLTAGE LINES (GREATER THAN 1000 V ALTERNATING CURRENT OR 1500 V DIRECT CURRENT) IS EXPRESSLY FORBIDDEN.**

## 6 OPERATION

### 6.1 Preliminary operations

Before starting the ceiling fan, check that:

- 1) All electrical connections have been formed according to the instructions given in this manual;
- 2) The ceiling fan is free and clean;



### 6.2 Starting for the first time

Once assembly, installation and the electrical connection for the machine have been completed, power the machine and wait for about 30 seconds to allow it to complete a self-diagnosis of its default parameters, and then start rotating. Subsequently, check that:

- a. There is no imbalance in the installation due to incorrect assembly of components, or latent defects in the same.
- b. There are no metal noises or sounds coming from the machine itself.
- c. The motor's diagnosis LED flashes every 2 seconds.
- d. Rotation is clockwise, when looked at from below the ceiling fan.



### 6.3 Emergency stoppage

In an emergency, switch off the power supply to the machine via the circuit breaker or the main power supply set up. Warning! Do not touch the machine for a period of 5 minutes after switching off the power, because the outside temperature of the machine may exceed 70°C.

### 6.4 Starting

The machine starts automatically as soon as electricity is supplied to it, after a delay of about 30 seconds to allow automatic setting of the operating parameters. To start the ceiling fan correctly, see the installation manual enclosed with this manual. The fan speed is adjustable by a potentiometer standard supplied. The maximum fan speed is indicated in the 8.1 Technical Data Table.

## 7 MAINTENANCE



**Before doing any maintenance work, isolate the equipment from the power supply!**

### 7.1 Routine maintenance

The product must be kept clean and protected against agents that may harm its integrity or use. The machine does not require routine maintenance.

### 7.2 Periodic checking

Frequency	Activity	Activity	Activity	Activity	Activity	Activity
Daily	1					
Monthly	1	2				
Sixmonthly	1	2	3			
Yearly	1	2	3	4		
2 Years	1	2	3	4	5	
5 Years	1	2	3	4	5	6

#### Activity legend

1	Visual check Check direction of rotation Check abnormal vibrations Check LED operation
2	Check structural integrity Check star shaped blade fixing General cleaning
3	Check screws tightening and resistance Check blade integrity Check connector power and signal
4	Full cleaning by dust and other
5	Check bracket and screw tightening Check anti-fall plate tightening (where required)
6	Check state of corrosion or oxidation

### 7.3 Extraordinary maintenance

Extraordinary maintenance refers to work on the electronic board, and replacing blades or other mechanical parts. The methods are described in the assembly manual enclosed.

ALL maintenance operations, including extraordinary maintenance tasks, must be strictly done with the machine stopped and disconnected from the electricity supply, by a specialist operator trained as indicated in this manual. All precautions must be taken to avoid anyone inadvertently powering the plant while extraordinary maintenance work is in progress. We therefore recommend adequately indicating the fact that the power must not be switched on during the operations, using suitable means (e.g. locking the electrical panel with a key). The specialist personnel involved must wear specific personal protection equipment, especially working gloves, protective hard hat, and safety footwear. For work done at a height, adequate means must be used such as a scaffold or mobile platform that can be raised. All of these must have strong hand railings in good condition. Personnel working at a height must be equipped with the necessary devices to prevent them falling. At the time of the work, the personnel must ensure that they are not exposed to a risk of being struck by another ceiling fan, adjacent to the one they are working on. If this is the case, the other machine must also be disconnected. On completion of the operations, before powering the machine again, all the people and equipment involved in the works must be removed and take a safe distance to the side of the blades of about 1 m, while below the machine there must be no impediment within about 2,7 m of the fan.

### Maintenance records

We believe that for safe use of the product it is important that the user sets up a suitable register for routine checks and maintenance done, in the form called for by applicable local norms. This may be based on the "Periodic Check" table above, which may be developed graphically to form a checklist with tick boxes for the individual tasks carried out.

We recommend that accurate records be kept of each activity and/or maintenance task and/or replacement, indicating the operator, with adequate space for recording any anomaly or problem encountered.

We recommend that the safety instruction warning be clearly visible on the register as well: "If in doubt as to any operation being carried out on the machine, interrupt the work, make the machine completely safe, and contact the manufacturer to obtain the necessary technical clarifications".

## 8 TECHNICAL CHARACTERISTICS

### 8.1 Technical data

Data	Destrat. NORDIK 300/120"	Destrat. NORDIK 400/160"	Destrat. NORDIK 500/200"	Destrat. NORDIK 600/240"	Destrat. NORDIK 700/280"
<b>Motor Unit Weight</b>	61 Kg	61 Kg	69,5 Kg	69,5 Kg	80 Kg
<b>Blade Weight</b>	19,5 Kg	27 Kg	34,5 Kg	42 Kg	49,5 Kg
<b>Total Weight</b>	80,5 Kg	88 Kg	104 Kg	111,5 Kg	119,5 Kg
<b>Max Consumption [W]</b>	600	648	831	843	900
<b>Power supply</b>	400 V 50 Hz				
<b>Current Absorbed [A]</b>	1,43	1,67	1,97	2,02	2,12
<b>Max. speed [RPM]</b>	160	100	75	55	38

## 8.2 Spare parts list

Only original spare parts are to be used for all units made by Vortice S.p.A. The manufacturer does not accept any responsibility resulting from the use, assembly, removal, insertion, connection or any other operation in the machine, done using pirate parts or parts not expressly approved by Vortice S.p.A., as well as any works done by operators not authorised for the purpose by the Manufacturer, or trained by them.



Orders are to be made, indicating the following information:

- Equipment model
- Item reference as shown in the drawing.
- Quantities of parts ordered
- Client's address

pos.	image	description	code
1		Motor + Inverter	Motor H20: 500012 Motor H40: 500019
2		Inverter, with box	599004
3		Individual blade	Pala 3m Codice: 501208 Pala 4m Codice: 501209 Pala 5m Codice: 501210 Pala 6m Codice: 501211 Pala 7m Codice: 501213
4		Tie Bar Kit	21136

## 9 TROUBLESHOOTING



**Before doing any maintenance work, isolate the equipment from the power supply and shut off the water supply!**

PROBLEM	CAUSE	SOLUTION
The machine does not start	The power is not on.	Check the electrical connection or the mains power supply.
The fan does not start.	The power supply to the motor is not on.	Check the electricity supply to the motor.
	The motor is faulty.	Contact specialist, authorised personnel to replace the motor.
The machine vibrates	The fan is dirty or broken.	Contact specialist, authorised personnel to replace the fan.

**Vortice Elettrosociali S.p.A.**

Strada Cerca, 2  
 Frazione di Zoate  
 20067 Tribiano (Milano)  
 ITALY


Ph: (+39) 02 906991

[www.vortice-italy.com](http://www.vortice-italy.com)

# **Annex 1**

## **Assembly Instructions**

## *Assembly blade support to motor*



*501271  
BLADE SUPPORT*



*501183  
FIXING PLATE*



*501196  
HUB*




*901468 SCREW M10x45 TE  
901467 SELFBLOCK BOLT M10  
901466 NUTS 10,5x20 h2*



*901481 SCREW M10x35 TE  
901016 NUTS GROWER D.10*



## *Assembly blade support to motor*



*INSERT PLATE INTO BLADE SUPPORT USING  
SCREWS M10x45 TE  
NUT. 10,5x20 h2*

***ATTENTION:***  
*Check right side of Blade Support*

*Assembly blade support to motor*



***ATTENTION:***  
*Place hub with tab seats oriented as  
per picture at side*

***POSITION HUB AND CLOSE NUTS 10,5x20 h2  
TO SELFBLOCKING BOLT M10***

## *Assembly Blade Support on Motor*



*PLACE BLADE SUPPORT WITH DISC OVER THE SHAFT AND CLAMP SCREWS M10x35 TE WITH NUTS GROWER D.10*

## *Safety holder assembly (when needed)*



*501201  
SAFETY HOLDER*



*SCREW M8x25 TCEI INOX  
(already available into motor)  
NUT. GROWER D.8  
(already available into motor)*

*Safety holder assembly (when needed)*



*PLACE SAFETY HOLDER AND FIX THEM WITH SCREWS (Already available into motor)*

## *Assembly motor holder*



*501185  
MOTOR HOLDER*




*901467 SELFBLOCKING BOLT M10  
901466 NUT 10,5x20 h2*

*POSITION MOTOR HOLDER OVER MOTOR  
CLAMP NUTS AND BOLTS*

## *Assembly Winglet on blade*



*POSITION THE WINGLET AT BLADE TIP  
FIX WITH PROVIDED SCREWS and NUTS*



*501272  
WINGLET*



*901486 SCREW M8x45 TCEI  
901473 WASHER 8,4x16 h1,6  
901474 SELFBLOCKING BOLT. M8*



*BLADE  
Code indicated in the Component table*

***Assembly blades on support– Assembly to be made after fan positioned at final destination***



901484 SCREW M8x60 TCEI  
901485 NUT 8,4x24 h2  
901474 SELFBLOCKING BOLT M8



***Blade's top face fixed with selflocking Bolts***

***ATTENTION:***

***Screws must be assembled with the head of the screw on the bottom face of each blade.***

***PLACE BLADE INTO FIXING BLADE.  
FIX THEM WITH SCREWS, NUTS AND BOLTS.***

## *Assembly rod holder and rod*



### **ATTENTION:**

*Rod holder position is in rod side with 2 holes*



501184  
ROD HOLDER



901470 SCREW M12x90 TE  
901469 NUT D,14x36 h2,5  
901471 SELFBLOCKING BOLT M12



501190 ROD




901470 SCREW M12x90 TE  
901469 NUT. D,14x36 h2,5  
901471 SELFBLOCKING BOLT M12



## *Assembly rod holder and rod*



*PLACE ROD INTO MOTOR HOLDER AND FIX WITH  
SCREWS, NUTS AND BOLTS*



## *Assembly rod holder and rod*



*PLACE ROD INTO ROD HOLDER AND FIX WITH SCREW, NUTS AND BOLTS*

*ASSEMBLY POSITION FOR ROD HOLDER DEPENDS ON INSTALLATION STUDY AND DESIGN*

*Assembly Spider - Material*



*501271 Main Spider*



*501264 Reinforced Spider folded + Spacer*



*901486 SCREW M8x45 TCEI*

*901485 NUT 8,4x24 h2*

*901474 SELFBL. BOLT M8*

*To assemble 5 central screws Reinforced Spider to Main Spider*




*501273 Bottom cap*

## *Assembly Spider - Instructions*

*For a correct assembly it is necessary follow the correct sequence, as indicated:*




- *Fix the Main Spider to the Hub*
- *Put the blades in the Main Spider's spokes centering the blade mounting holes (by using a screwdriver)*
- *Fix without tightening the external screw for each blade with bolts and nuts*



- *Fix without tightening the 5 central screws of the reinforced spider to the main one, with bolts and nuts*


## *Assembly Spider - Instructions*



- *Put the other 2 screws in each blade without tightening with bolts and nuts*
- *Tight the 5 central screws already fixed.*
- *Tight the screws to fix the blades*
- *Put the hooks of the bottom cap into the holes of the spacer*

*N.B: The M8 screws tightening torque is 27 Nm*

### *Assembly Fan completed*



*Clockwise rotation (bottom view)*



*CONNECT CONTROLLER LINE AND POWER LINE*

### ***First Start***

*After having assembled complete fan, connected power and controller lines, give power to machine and wait about 30 seconds until it start to run, because machine need 30 seconds to autosest all parmeters.*

*After that check following:*

- *No rotation unbalancing due to wrong components assembly*
- *No noise coming out from machine*
- *Motor led light every 2 seconds to test everything is fine*
- *Fan Rotation must be clockwise, if seen from below the fan.*

*Assembly PCB on motor – Possible to do also with motor fixed to the roof*



*PC BOARD*



*POWER AND SIGNAL CON-  
NECTORS*



*501161 M6x16 TCEI*

## *Connector cables insulation*





*USE AROUND CABLE ONE SHEATH TO INCREASE THICKNESS AND HAVE OPTIMUM CLOSING*




*IT'S MANDATORY PROTECT BACK PART OF CONNECTORS FROM HUMIDITY OR DIRT USING INSULATING COIL OR SOME OTHER MATERIAL THERMALLY SHRINKABLE*

# Tie Bar Kit




DETTAGLIO A  
DETAIL A



DETTAGLIO B  
DETAIL B

*Assembly PCB on motor – Possible to do also with motor fixed to the roof*



*501161 M6x16 TCEI*



*Lean Pc Board to connect power line and probe – ATTENTION to colours:  
U – BLACK / V – GREY / W – BROWN  
Assembly PC board to motor and clamp it.*

*Disassembly Fan – POWER – Operation with motoinverter connectet to the roof*



***DISCONNECT POWER  
DISCONNECT BOTH OF TWO CONNECTORS FROM FAN***

***Disassembly Fan – POWER – Operation with motoinverter connectet to the roof***



- 901484 SCREW M8x60 TCEI
- 901485 NUT 8,4x24 h2
- 901474 SELFBLOCKING BOLT M8

***UNSCREW AND DISASSEMBLY BLADES***


***ATTENTION:***

***Operation require you use adequate support to substain blades and their weight, so please prepare everything before start operation***

***Disassembly fan- WINGLET – Operation to be made with blade to the ground***



*Svitare vite che tiene fissato il Winglet plastico alla pala.*



*501272  
WINGLET*




*901486 SCREW M8x45 TCEI  
901473 WASHER 8,4x16 h6  
901474 SELFBLOCKING BOLT M8*



*BLADE*

***Disassembly fan- MOTOINVERTER – Operation to be made with motoinverter fixed to the roof***



901470 SCREW M12x90 TE  
901469 NUT D,14x36 h2,5  
901471 SELFBLOC. BOLT M12

***UNSCREW MOTOR HOLDER FROM ROD***

***ATTENTION:***

***Operation require you use adequate support to substain blades and their weight, so please prepare everything before start operation***

***Disassembly fan– Blades support - Operation with Motoinverter on floor***



***UNSCREW MOTOR HOLDER FROM MOTOINVERTER***



**501185**  
**MOTOR HOLDER**



**901467 SELFLOCKING BOLT M10**  
**901466 NUT 10,5x20 h2**

***ATTENTION:***

***Use adequate support to avoid support blade to be direct in contact with floor***

***Disassembly fan– BLADE SUPPORT- Operation to be done with motoin-  
verter on the floor***



901468 SCREW M10x45 TE  
901467 SELFBLOCKING BOLT M10  
901466 NUT 10,5x20 h2



901481 SCREW M10x35 TE  
901016 NUT GROWER D.10



501271  
MAIN SPIDER



501183  
FIXING BLADE

***UNSCREW BLADE SUPPORT FROM SHAFT AND HUB AND TAKE OUT PARTS***

***ATTENTION:***

***Rotate motor 180° to execute operation***

## *Disassembly fan– HUB- Operation with Motoinverter to the floor*



*AFTER DISASSEMBLED BLADE SUPPORT, DISASSEMBLY*



*501196  
HUB*



*501201 SAFETY HOLDER*



*SCREW M8x25 TCEI SS  
NUT GROWER D.8*



### **ATTENTION:**

- A – The Hub is strongly connected to the shaft – You will need adequate extractor.*
- B – If present safety holder, before unscrew hubs disassembly safety holder*

## *Disassembly fan- PCB*



*ROTATE 180° MOTOR*



*UNSCREW THE SCREWS*



*DISCONNECT CABLE*



*PCB*



*501161 M6x16 TCEI*

### ***ATTENTION:***

*Avoid to place directly in contact shaft with floor to avoid damage*

# **Electric connection**

## **Power connection**

*HVLS fan must be powered by 3F+G 400V 50 Hz through a line realized with wire kind FG7OR composed 4G2.5 or higher related to present load.*

*Energy power distribution is composed according to wire diagram supplied.*

*Power panel protect in MT (magnetotermic protection) line powering HVLS fan in one single area.*

*Every single HVLS fans line must be protected.*

*Power panel must be supplied by a dedicated line 3F+N+G 400V 50 Hz protected by adequate MT protection (minimum 20 A) and from a protection **Differential A type**.*

*The PE cable must be connected to a grounding system with impedance and characteristics such as to ensure the proper operating of the differential protections installed in accordance with regulations about indirect contact and no dissipation of stray currents.*

**Attention: line with MT+D (magnetotermic protection + HVLS fan) must be dedicated and not powered together with other devices. Cannot be derived from other differential A type.**

*HVLS fan must be connected with its own connector to signal wire.*

*Togheter with power wire will be installed analogic signal wire (0-10 v tension for fan speed control) and modbus signal able to control fan and modify parameter through a remote PC.*

*For analogic signal will be used a RS485 wire (2\*2\*AWG24 twisted and shielded).*

*Shilded wire must be provided only from power panel side and not from fan side.*

*In case on signal line you are going to install junction boxes to connect single fan signal line to main line, between junction boxes and signal connector from inverter you must use same wire RS485 used for signal line.*

*For connection and wire colour, you have to follow electric diagram.*


## ***Warnings for maintenance and diagnostic actions***

***Many maintenance interventions and diagnostic actions of the fan can be done by remote connection.***


***In order to do this, it is, however, necessary to identify exactly the fan and connect to it.***

***Therefore, DURING THE INSTALLATION IT IS MANDATORY:***

- 1) Pull always the A and B wires down to the switchboard (to connect with the fan)***
- 2) Set down in a scheme the Serial Number and the Modbus Address of each motor, as well as their placement (to univocally identify each single machine) in case of maintenance***
- 3) Verify that in the same line there are not installed two motors with identical Modbus Addresses.***




*Modbus Address label*




*Motoinverter type and Serial  
Number label*

*Inverter parameterization  
Blades Diameter Set label*


# Fan line connection scheme



# Existing plant wiring scheme




# Multiwire system wiring Scheme



CONNETTORI VISTA LATO SALDATURA  
SIDE WELDING VIEW


CONNETTORE ALIMENTAZIONE  
SUPPLY CONNECTOR



PIN

A : L3  
B : L2  
C : L1  
D : PE

CONNETTORE SEGNALE  
IN/OUT CONNECTOR




PIN

A : MODBUS A  
B : MODBUS B  
C : OUT  
D : DIG IN  
E : +10V-I  
F : ANALOGIC IN (0-10V)  
G : GND-I


CONNETTORI VISTA LATO SALDATURA  
SIDE WELDING VIEW

CONNETTORE ALIMENTAZIONE  
SUPPLY CONNECTOR



DISPOSITIVO DA PREVEDERE  
IN FASE DI INSTALLAZIONE  
DEVICE TO PROVIDE  
DURING INSTALLATION

INTERRUTTORE  
SWITCH  
SELETORE  
SELECTOR SWITCH  
RELE'  
RELAY



SENSO ROTAZIONE

ORARIO : DIG IN non connesso


ANTIORARIO : DIG IN connesso a GND

SENSE ROTATION

CLOCKWISE : DIG IN not connected

COUNTERCLOCKWISE : DIG IN connected to GND


CONNETTORI VISTA LATO SALDATURA  
SIDE WELDING VIEW



**NB: It is necessary pull the A and B wires down to the control box for the Modbus connection, used for maintenance and diagnostic actions.**


Electric Scheme - Option 1:  
External Potentiometer  
Vortice code: 12832

CONNETTORI VISTA LATO SALDATURA  
SIDE WELDING VIEW



**NB: It is necessary pull the A and B wires down to the control box for the Modbus connection, used for maintenance and diagnostic actions.**

Electric Scheme - Option 2:  
External Potentiometer with DIN box  
Vortice code: 12828



**NB: It is necessary pull the A and B wires down to the control box for the Modbus connection, used for maintenance and diagnostic actions.**

Electric Scheme - Option 3:  
 VORT T Control Box  
 Vortice Code: 21137

## IMPORTANT INFORMATION ON ENVIRONMENTALLY COMPATIBLE DISPOSAL

In certain European Union countries this appliance is not subject to the requirements of national laws implementing the WEEE Directive; consequently, there is no obligation to observe sorted collection procedures when disposing of the appliance in these countries.

This appliance complies with European Directive 2002/96/EC.

Where an appliance is marked with the crossed-out wheelee bin symbol, this means that, at the end of its useful life, the product has to be disposed of separately from household waste: it must be taken to a sorted collection centre for electrical and electronic appliances or returned to the retailer when a new equivalent appliance is purchased.



The user is responsible for taking the appliance to a designated collection centre at the end of its useful life, and liable to penalties applicable under current statutory regulations on waste disposal.

Appropriate sorted waste collection for subsequent recycling, treatment and eco-compatible disposal of decommissioned appliances helps to prevent any possible negative impact on the environment and on health, and favours recycling of the materials used in the manufacture of the product.

For more detailed information on available waste collection systems, contact the local waste disposal service or the shop where the product was purchased.

Manufacturers and importers comply with their responsibility for recycling, treating and eco-compatible disposal of waste both directly and collectively.

## WARNINGS

- This appliance can be used by children no less than 8 years of age and by individuals with limited physical, sensory or mental capacities, or by inexperienced or untrained individuals, provided that they are supervised or have been instructed in safe use of the appliance and understand the associated risks. Children must not play with the appliance. Cleaning and maintenance procedures that can be undertaken by the user must not be entrusted to children, unless under supervision.
- The appliance must be installed by a professionally qualified electrician.
- A multi-pole switch must be used to install the appliance. The contact opening gap must be no less than 3 mm.



Vortice S.p.A. reserves the right to make improvements to products at any time and without prior notice.